

Lighting and Marking Recommendations for Animal-Drawn Carriages, Buggies and Wagons

Authored by Robert "Bobby" Grisso, Extension Engineer, Biological Systems Engineering, Virginia Tech S. Dee Jepsen, Associate Professor, Agricultural Safety and Health, The Ohio State University

Introduction

Horse-drawn buggies or wagons and other animaldrawn carriages have been used by the Plain Communities as the primary means of transportation for generations. Equestrian sports and tourism business enterprises have also increased the number of horse-drawn carriages on streets and highways.

In this document, buggies, carriages, wagons, and other animal drawn vehicles will be referred to as buggies. While the use of buggy transportation has remained steady, the population in rural communities has grown, and tourism in Plain Communities has increased. These changes have resulted in increased sharing of roadways by motor vehicles and buggies and more accidents.

Universal buggy lighting and marking recommendations can be used effectively to reduce buggy/motor vehicle crashes and buggy users must be encouraged to use these recommendations to avoid or reduce the number of accidents.

Several state and county agencies and law enforcement agencies have been working together to develop recommendations for the marking and lighting of buggies. Currently, Virginia lacks recommendations or regulations with this regard except for the use of the Slow Moving Vehicle (SMV) emblem.

ASABE developed engineering standards for lighting and marking animal-drawn vehicles, and buggies. These standards provide a unique lighting and marking pattern for animal-drawn vehicles (Figures 1-3) and are the goal of this document. The ASABE standard recommends the use of a battery or generator powered lighting system. Batteries recommended are typical storage, deep-cycle, or gel cell batteries.

Battery systems, wiring and lighting kits, may be obtained from suppliers of specialty and recreational horse-driven vehicles. Less expensive sources of such kits may exist; but are not readily available from internet-based sources. An example of such a source in Virginia is:

Burkholder Buggy Shop 795 Mason Street, Dayton, VA 22821-9700 (540) 879-9260

During installation, all wiring, connections and switches should be securely fastened to the vehicles and protected from moving parts, water and corrosion. The recommended placement of lights and reflective devices are shown in Figures 1-3.

Generally, battery is the only power source available on the vehicle for the light system. Therefore, a fully charged battery is critical for keeping the lights on and improving vehicle visibility. Batteries require maintenance and for this reason the manufacturer's recommendations must be followed.

Battery and charging systems should be properly matched and easy to connect (figure 4). Most buggies will securely mounted batteries under the seat or trunk with quick access for the charger clamps (see example below). If electric power is not available, solar panel chargers are an alternative. Solar panels can be mounted on the storage shed. Make sure that the wiring associated with charging system has no opportunity to get cut.



Figure 4. Battery with special terminals with charger connections (left) and the connection for the light system (lower right).

It is a good practice to recharge the battery when the carriage is not in use. This will assure fully charged lighting system for highway travel.

An important issue to consider is backup lighting in the event lights go out due to dead batteries, burned out bulbs, or malfunctioning of the total lighting system. Given the challenge of maintaining functional emergency backup systems, multiple backup measures are suggested. Passive markings generally used during day-time should be upgraded to make the visible in dark if the lighting system fails. Low-voltage systems, such as LED based systems are preferred as backup system. LED (lightemitting diode) systems are readily available and one or two additional units as backups would be desirable.

Also shown in Figures 1-3 are leg wraps for horses. Fluorescent ankle wraps for horses pulling the buggies "glow" in low light and capture the attention of motorists to slow down. Marking the horse as well as the vehicle will allow motorists to judge the total length of horse and buggy more accurately during passing or when making left hand turns.

Slow Moving Vehicle (SMV)

The SMV emblem are widely used on vehicles traveling slower than 25 mph. Studies have shown that two out of three highway crashes involving slow-moving vehicles are rear-end collisions. Of these rear-end collisions; nine out of ten occur during day time. During the day time, the bright, fluorescent orange triangle of the SMV emblem gets the attention of the motorists from more than 1,000 feet away. This provides the motorists ample time to slow down before it is too late. At night, the reflective border of the SMV emblem glows brightly with bright headlights. The distinctive, retroreflective red triangle surrounding the fluorescent orange center immediately identifies a slow-moving vehicle.



Acknowledgements

The authors would like to express our appreciation to former co-authors, Kirk Ballin, John Perumpral and Don Ohanehi for their input in previous versions.

This publication was developed with the support of the National AgrAbility Program. The AgrAbility Virginia Program is funded by the AgrAbility Project, USDA National Institute of Food and Agriculture (NIFA), Special Project 2019-41590-30127. Administered by Virginia Tech, Virginia State University, and Easter Seals UCP North Carolina & Virginia, Inc. ww.agrabilityvirginia.org The authors that developed this publication is solely responsible for its content, and it does not necessarily reflect the views of the USDA/ NIFA.

References

Agricultural Equipment on Public Roads. 2009. North Central Education/Extension Research Activity Committee 197. Cooperative State Research, Education, and Extension Service. United State Department of Agriculture. Retrieved at: https://nasdonline.org/2065/d001906/agricultural

-equipment-on-public-roads.html

ANSI/ASAE EP576.2 October 2012. Lighting and Marking of Animal-Drawn Equipment, ASAE Standards, American Society of Agricultural and Biological Engineers (ASABE), St. Joseph, MI 49085. Jepsen, S.D. and T. Calip. 2014. *Lighting and Marking Recommendations for Pony Carts and Other Low-Profile, Animal-Drawn Vehicles.* The Ohio State University, Extension Publication AEX-596.9.

Resources

Murphy, D.J. 2020. *Rx for SMV Highway Safety: Be Conspicuous*, ART-2473, Agricultural and Biological Engineering, Cooperative Extension, Pennsylvania State University, University Park, PA.

Pennsylvania DOT. 2008. *Horse and Buggy Driver's Manual*, PUB 632 (10-08). Available from: http://www.justdrivepa.org/Resources/Amish%2 0Horse%20and%20Buggy%20Manual.pdf

Visit Virginia Cooperative Extension: ext.vt.edu

Virginia Cooperative Extension programs and employment are open to all, regardless of age, color, disability, gender, gender identity, gender expression, national origin, political affiliation, race, religion, sexual orientation, genetic information, veteran status, or any other basis protected by law. An equal opportunity/affirmative action employer. Issued in furtherance of Cooperative Extension work, Virginia Polytechnic Institute and State University, Virginia State University, and the U.S. Department of Agriculture cooperating. Edwin J. Jones, Director, Virginia Cooperative Extension, Virginia Tech, Blacksburg; M. Ray McKinnie, Administrator, 1890 Extension Program, Virginia State University, Petersburg.

2020

3006-1454 (BSE-333NP)

Table 1. Summary of the ASABE Engineering Practice and Virginia recommendations for animal-drawn buggy lighting and marking

ltem	Number	Color	Mounting	Options
SMV Emblem	1	RED retroreflective	Rear center, 2 to 6	No alternative options exist for
(Rear)		border surrounding	feet from the	an SMV emblem.
		fluorescent	surface of the road.	
		ORANGE center		
Headlights1 (Front)	At least 2	WHITE	Symmetrically	As an alternative to headlamps
			around centerline,	and tail lamps, at least two
			mounted between	double-faced lamps protruding
			2.5 and 5 feet high,	from the sides at the widest
			visible to the front	point can be used. The lamps
			and the rear.	will have a CLEAR lens to the
				front and a RED lens to the rear.
Tail Lights₁ (Rear)	At least 2	RED	Symmetrically as	A turn signal system may be
			widely spaced as	incorporated into the rear RED
			possible, between	tail lamps or the flashing
			2.5 and 4 feet high.	AMBER lamps. In that case, the
				lamp that is positioned on the side of the turn should flash and
				the lamp on the side away from
				the turn should go to steady
				burn.
Hazard Flashers	At least 2	AMBER	Symmetrically,	No other options exist for
(Front and Rear)		ANDER	visible to front and	AMBER flashing lights. An LED
(rear, between 2.5	light may be mounted on the top
			and 7 feet high.	center.
Retroreflective	2-inch x 9-inch	Alternating RED	Outlining the sides	Where local culture uses WHITE
Material (Rear)	strips	retroreflective and	and top of the rear	retroreflective material, it should
		ORANGE RED	of the vehicle.	be at least 1-inch wide. If this
		fluorescent material		option is chosen, two red reflex
				reflectors or red retroreflective
				material should be mounted
				symmetrically around centerline,
				as widely spaced as possible.
Retroreflective	At least two 2-inch	YELLOW	Symmetrically along	Where local culture uses WHITE
Material (Side)	x 9-inch strips	retroreflective	each side of vehicle	retroreflective material, it should
		material	frame. If vehicle has	be at least 1-inch wide.
			a tongue or shaft	
			visible on the	YELLOW or WHITE
			outside of the	retroreflective material may be
			animal, at least one	attached to the harness, to the
			additional yellow	animal's legs, or both.
			strip should be	
			placed on outside of	
			the tongue or shaft.	

Animal-drawn vehicles with a lighting system should be equipped with a battery operated or generator powered system. Batteries may be typical storage, deep cycle or gel cell.



Figure 1. Recommended light and reflective materials for horse drawn wagons.



Figure 2. Recommended light and reflective materials for a horse-drawn buggy.



Figure 3. Recommended light and reflective materials for horse-drawn.